

Sicherheitshinweise, Pflege und Wartung:

- Bewahren Sie das Gerät vor extrem hohen und niedrigen Temperaturen, vor direkter Sonneneinstrahlung sowie Wasser, Feuchtigkeit und Flüssigkeiten. Lagerung bei -20 to 20°C.
- Verwenden Sie keine scheuernden Reinigungsmittel oder scharfen Gegenstände.
- Halten Sie das Gerät frei von Staub, Flusen etc.
- Außerhalb der Reichweite von Kindern aufbewahren. Plastiktüten, Folien und andere Verpackungsmaterialien können zum Ersticken führen.
- Werfen Sie das Gerät nicht ins Feuer (Explosionsgefahr)
- Versuchen Sie nicht, das Gerät zu zerlegen.
- Reparaturen an elektrischen Geräten sollten nur von einem qualifizierten Fachmann durchgeführt werden.
- Verwenden Sie das Gerät NICHT, wenn es feucht ist, um die Gefahr eines Stromschlags, Explosionen oder Selbstverletzungen zu vermeiden.
- NICHT verwenden, wenn das Gerät fallen gelassen oder beschädigt wurde.
- Bei Rauchentwicklung, ungewöhnlichen Geräuschen oder starker Hitzeentwicklung bringen Sie die Powerbank an einen sicheren Ort im Freien.

Im Falle eines Brandes löschen und kühlen Sie mit ausreichend Wasser und alarmieren im Zweifelsfall die Feuerwehr. Lithium-Ionen-Akkus können auch nach dem Löschen noch für längere Zeit rückzündet.

Lagern Sie den gelöschten Akku / das gelöschte Gerät aus diesem Grund auch nach dem Ablöschen in einem Wasserbecken oder einem anderen geeigneten Behältnis.

Safety Instructions, care and maintenance

- Keep the device away from extremely high and low temperatures, direct sunlight, water, moisture and liquids. Store at -20 to 20°C.
- Do not use abrasive cleaning agents or sharp objects.
- Keep the device free of dust, lint, etc.
- Keep out of the reach of children. Plastic bags, foils and other packaging materials can cause suffocation.
- Do not throw the appliance into a fire (risk of explosion)
- Do not attempt to dismantle the appliance.
- Repairs to electrical appliances should only be carried out by a qualified technician.
- DO NOT use the appliance when it is wet to avoid the risk of electric shock, explosion or self-harm.
- DO NOT use if the appliance has been dropped or damaged.
- In the event of smoke, unusual noises or excessive heat, move the power bank

to a safe place outdoors. In the event of a fire, extinguish and cool with sufficient water and, if in doubt, alert the fire brigade. Lithium-ion batteries can continue to reignite for a long time after extinguishing.

For this reason, store the extinguished battery/device in a basin of water or other suitable container even after extinguishing- DO NOT use if the unit is moist in order to avoid danger of electric shock, explosions or injuring yourself

- DO NOT use if the unit has been dropped or damaged

- In the event of smoke, unusual noises or excessive heat, move the power bank to a safe place outdoors.

In the event of a fire, extinguish and cool with sufficient water and, if in doubt, alert the fire brigade. Lithium-ion batteries can continue to reignite for a long time after extinguishing. For this reason, store the extinguished battery/device in a basin of water or other suitable container even after extinguishing.

- Do not crush or puncture the battery and do not immerse it in liquids.